


1kw + FM910-4 Power Station Wiring Diagram



Panels Wired in Series




Turbine cable is to be extended within the pole using the twin core cable provided. Connect the battery to the regulator before the turbine. Construct the tower and rigging kit as per the instructions provided.

Push MC4 connectors together until you hear the click

Bluetooth monitoring available via this charge controller, using an app on mobile phone





Connect the battery to the charge controller first



The AC IN can support a generator, shore power or mains power supply which will be used to charge the batteries. With power assist, the Multi will provide power when the AC supply cannot meet power demands.



Batteries Wired in Series for 165Ah, 24V



AC Distribution Board

This diagram serves as an example to show how the equipment should be wired together; manufacturer's instructions should be read prior to installation. Select Solar are unable to accept any responsibility for damage caused by cross polarity. If there is any doubt, please contact us before connecting any cables.

Grounding in accordance with manufacturer's instructions.